

Issue

Screw length on the spool covers made it difficult to install the filter tape.

Symptoms

When changing the filter tape the PVC take up spool might be difficult to thread the spool cover into. This is due to the much denser material of the PVC compared with the cardboard spools of the filter tape

Solution

All spool covers have an 1/8" longer screw.

Contact Information

Mike Putnam

541.471.7115 x 133

service@metone.com



Met One Instruments, Inc.

Corporate Sales & Service: 1600 Washington Blvd., Grants Pass, OR 97526, Phone: 1(541)471-7111, FAX: 1(541)471-7116
Regional Service: 3206 Main Street, Suite 106, Rowlett, TX 75088, Phone: 1(972)412-4747, FAX: 1(972)412-4716
Website: www.metone.com Email: service@metone.com
